

## ASSEMBLY





**STEP 2.** Position the assembly upright. To attach the feet, align the holes in each foot with the holes in the center beams. The slant on the base of the foot should angle the foot in towards the center of the stand. Insert (4) carriage bolts, (4) flat washers, and (4) hex nuts like shown in the diagram. **Tighten all bolts.** 

**NOTE.** Recommended use of the three rubber/plastic caps provided, to cover the exposed ends of the eye bolt and hex bolts

Congratulations on purchasing this Roman Arc Cypress Hammock Stand. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 800.643.3522.