


# CONVERSATION CHAIR INSTRUCTIONS




## ASSEMBLY

**STEP 1.** Use (14) 2" barrel bolts, (14) barrel nuts and (2) pegs to attach right and left arm assemblies to chair seat and frame assembly. Keep all barrel bolts loose until Step 4. (Name plate and spreader hidden for view)


RIGHT ARM ASSEMBLY

LEFT ARM ASSEMBLY



## HARDWARE PACK

Hardware Pack Weight: 11.8 oz.



## CHAIR PARTS


- CHAIR BACK
- CHAIR SEAT
- RIGHT ARM ASSEMBLY
- LEFT ARM ASSEMBLY
- FRAME ASSEMBLY

## SUGGESTED TOOLS


- RUBBER MALLET
- KNIFE OR SCISSORS
- PHILLIPS HEAD SCREWDRIVER
- DRILL

## ASSEMBLY

**STEP 2.** Use (2) 1.5" barrel bolts and barrel nuts to attach chair back to right and left arm assemblies.



**STEP 3.** Use (2) 2" screws to attach chair back to chair seat. Tighten all bolts once screws are in.



**Congratulations on purchasing this Conversation Chair. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 252-758-0641.**

**RESIDENTIAL WARRANTY** - This quality product includes a FULL LIFETIME WARRANTY for RESIDENTIAL CUSTOMERS. In the unlikely event any splintering, rotting, cracking, peeling, chipping, insect infestation or other damage should ever occur, The Hammock Source will replace this furniture, at no charge to you. Note that an original sales receipt must accompany any returned product, along with a Return Authorization Number from Hammock Source customer service; call toll-free at 252-758-0641.

**CONTRACTOR WARRANTY** - CONTRACTORS receive a FULL 7-YEAR WARRANTY. Follow the same steps outlined above.